

First:Check the Mainboard:
Second:Check the MB232a2.PCB
Third: Check the wire for connecting the comm.board




4.Unplug this wire for connecting the comm.board,and use the multimeter's black pen to press the black wire,and the red pen press the yellow ,brown or orange wire.Check if the voltage is 5 volt(normal)