

Gum Drop I/O Setting V1.0

打印时间 2018-6-1
修改时间 2014-8-11

Input :

INPUT	Content	INPUT	Content	INPUT	Content	INPUT	Content
I1	1# Coin	I11	#3 Score	I21	Holding Area Switch	I31	
I2	Bill Acceptor	I12	#4 Score	I22	Ball Release Mech. L	I32	
I3	Ticket SIGNAL / Clear	I13	#5 Score	I23	Ball Release Mech. R	I33	
I4	1 Ticket Feedback	I14	#6 Score	I24		I34	
I5	2 Ticket Feedback	I15	#7 Score	I25	Cursor SW Up	I35	
I6	Play Button	I16	#8 Score	I26	Cursor SW Down	I36	
I7		I17	#9 Score	I27	Setting SW	I37	
I8		I18		I28		I38	
I9	#1 Score	I19		I29		I39	
I10	#2 Score	I20		I30		I40	

Output:				SED Display			
INPUT	Content	INPUT	Content	INPUT	Content	INPUT	Content
OUT1		OUT17	#1 Target	OUT33	Coin Counter	SEG1_1	Target Score1-1
OUT2		OUT18	#2 Target	OUT34	Ticket Counter	SEG1_2	Target Score1-10
OUT3		OUT19	#3 Target	OUT35	1# Ticket Drive	SEG1_3	Target Score2-1
OUT4		OUT20	#4 Target	OUT36	2# Ticket Drive	SEG1_4	Target Score2-10
OUT5		OUT21	#5 Target	OUT37		SEG1_5	Target Score3-1
OUT6		OUT22	#6 Target	OUT38	Ball Drop Solenoid	SEG1_6	Target Score3-10
OUT7		OUT23	#7 Target	OUT39	Coin Lock	SEG1_7	Target Score4-1
OUT8		OUT24	#8 Target	OUT40	Collection Area Blower	SEG1_8	Target Score4-10
OUT9		OUT25		OUT41	Ground LED R	SEG2_1	Target Score6-1
OUT10		OUT26		OUT42	Ground LED G	SEG2_2	Target Score6-10
OUT11		OUT27		OUT43	Ground LED B	SEG2_3	Target Score7-1
OUT12		OUT28		OUT44	Button LED R	SEG2_4	Target Score7-10
OUT13		OUT29	Ball Direction Motor DIV	OUT45	Button LED G	SEG2_5	Target Score8-1
OUT14		OUT30	Ball Motor Direction Control	OUT46		SEG2_6	Target Score8-10
OUT15		OUT31	Fan Control	OUT47		SEG2_7	Target Score9-1
OUT16		OUT32	Ball Holding Area Solenoid	OUT48		SEG2_8	Target Score9-10

LMP-MCUC.PCB

INPUT	Content	Function
CN1	P30	Serial Port B
	P31	Serial Port A
CN2	P00	
CN2	P01	
CN2	P02	
CN2	P03	
CN2	P04	
CN2	P05	Front Vertical Cabinet LED
CN2	P06	CONSOLE LED
CN2	P07	Ball Release Mech LED

ERRO CODE

ERR-1	1# SCORE SW
ERR-2	2# SCORE SW
ERR-3	3# SCORE SW
ERR-4	4# SCORE SW
ERR-5	5# SCORE SW
ERR-6	6# SCORE SW
ERR-7	7# SCORE SW
ERR-8	8# SCORE SW
ERR-9	9# SCORE SW
ERR-10	RELEASE BALL BUTTON