Power Pong IO Chart

Item	Content	SW1-DIP Adjustment								
rtelli		SW11	SW12	SW13	SW14	SW15	SW16	SW17	SW18	
	1	ON	ON							
Credit	2	off	on							
	3	on	off							
	4	off	off							
	3			on	on	on				
	4			off	on	on				
Game	5			ON	OFF	ON				
Time	6			off	off	on				
(min)	8			on	on	off				
	10			off	on	off				
	15			on	off	off				
	unlimited			off	off	off				
	1						ON	ON	ON	
shape of	2						off	on	on	
Cup	3						on	off	on	
combinati	4						off	off	on	
on after	5						ON	ON	0FF	
hitting 3	6						off	on	off	
cups.	7						on	off	off	

SW2-DIP Adjustment

SW21 SW22 SW23 SW24 SW25 SW26 SW27 SW28

		g.o o	our c				
THEFT							OCEAN 8/3/2015
INPUT INPUT	Content	INPUT	Content	INPUT	Content	INPUT	Content
I1	1# Coln	I11	1#Falling Ball Sensor2	I21	2#MotorPositionSensor2	I31	2#Falling Ball Sensor6
12	(Extra Ball Reset)	I12	1#Falling Ball Sensor3	I22	2#MotorPositionSensor3	I32	ball output sensor
13		I13	1#Falling Ball Sensor4	I23	2#MotorPositionSensor4	133	StarGameButton
I4	1#MotorPositionSensor1	I14	1#Falling Ball Sensor5	I24	2#MotorPositionSensor5	I34	ExtraBallButton
15	1#MotorPositionSensor2	I15	1#Falling Ball Sensor6	I25	2#MotorPositionSensor6	135	StartGameWithBallButton
16	1#MotorPositionSensor3	I16		I26	2#Falling Ball Sensor1	I36	
17	1#MotorPositionSensor4	I17		I27	2#Falling Ball Sensor2	137	
18	1#MotorPositionSensor5	I18		I28	2#Falling Ball Sensor3	I38	
19	1#MotorPositionSensor6	I19		I29	2#Falling Ball Sensor4	I39	
I10	1# Falling Ball Sensor1	I20	2#MotorPositionSensor1	130	2#Falling Ball Sensor5	I40	

OUTPUT						SEG Displa	y:
OUTPUT	Content	OUTPUT	Content	OUTPUT	Content	OUTPUT	Content
OUT1		OUT17		OUT33	1#MotorDriver1	SEG1_1	
OUT2		OUT18		OUT34	1#MotorDriver2	SEG1_2	
OUT3		OUT19		OUT35	1#MotorDriver3	SEG1_3	
OUT4		OUT20		OUT36	1#MotorDriver4	SEG1_4	
OUT5		OUT21		OUT37	1#MotorDriver5	SEG1_5	
OUT6		OUT22		OUT38	1#MotorDriver6	SEG1_6	
OUT7		OUT23		OUT39		SEG1_7	
OUT8		OUT24		OUT40		SEG1_8	
OUT9		OUT25		OUT41	2#MotorDriver1	SEG2_1	
OUT10		OUT26		OUT42	2#MotorDriver2	SEG2_2	
OUT11		OUT27		OUT43	2#MotorDriver3	SEG2 3	
OUT12	欢迎	OUT28	CoinMetrDriver	OUT44	2#MotorDriver4	SEG2_4	
OUT13		OUT29	ExtraBallMeterDriver	OUT45	2#MotorDriver5	SEG2_5	
OUT14		OUT30	Start Game ButtonLed	OUT46	2#MotorDriver6	SEG2_6	
OUT15		OUT31	ExtraBall ButtonLed	OUT47	ExtraBallMotorDriver	SEG2_7	
OUT16		OUT32	StartGameWithBallButtonLed	OUT48	LOGO Led	SEG2_8	

Test the Main Board:

E

1.After SEG Display"t01"for 1 second, stop at "8.7.6.5.4.3.2.1."& "87654321".

(Test the SEG Display)

2.Press the "SERVICE" button 1 time, 7_Seg display "t02" 01 seconds,stop at "22222xxx/22222xxx", (Test SW DIP 1-3 State), the Dip SW1-SW3 State Display at "xxx";

3.Press the "SERVICE" button 1 time, 7_Seg display "t03" 1 second, stop at "3333xxxx/3333xxxx", (Test INPUT),

the input which is on will be display at <1>1-2,<1>3-4,<2>1-2,<2>3-4

4.Press the "SERVICE" button 1 time, 7_Seg display "t04" 1 second, stop at "4444xxxx/4444xxxx", (Test OUTPUT-1),

the input which is on will be display at <1>1-2,<1>3-4,<2>1-2,<2>3-4, and the OUTPUT will ON when the INPUT is on;

5.Press the "SERVICE" button , 7_Seg display "t05" 1 second, stop at "5555555xx/555555555", (Test OUTPUT-2),

the output 1-48 will ON one by one; and display the output number at <1>1-2

6.Press the "SERVICE" button , 7_Seg display "t06" 1 second,

stop at "666666xx/666666666", (Test Sound), Press the I02, the sound will be play, and the Number will be display at <1>1-2 7.Press the "TEST" again when in the "TEST MODE",Quit the "TEST Mode".

Note: Cup Combination after dropping ball(s)


I The shape of cup combination after all the cups go down.

II The shape of cup combination after the cups(certain ones) go down.

1.Shape of Cup combination after hitting 2 cups.



2. Shape of Cup combination after hitting 3 cups.



Combination	I	ON							
	II	off							
Ball Qty.	0		on	on	on				
(Extra	1		OFF	ON	ON				
Ball)	2		on	off	on				
	3		OFF	OFF	ON				
	4		on	on	off				
	5		off	on	off				
	6		on	off	off				
	7		off	off	off				
Ball Qty.	1					ON	ON	ON	
(Start	2					off	on	on	
game	3					ON	OFF	ON	
with	4					off	off	on	
ball)	5					on	on	off	
	6					off	on	off	
	7					on	off	off	
	8					off	off	off	
Game	+1(min)								ON
Time	+0(min)				_				OFF

Item

Content

ltem	Contont	SW3-DIP Adjustment								
item	Content	SW31	SW32	SW33	SW34	SW35	SW36	SW37	SW38	
Extra	1	ON	ON							
Ball	2	off	on							
(Coin)	3	on	off							
	4	off	off							
Start	0			on	on	on				
Game	1			OFF	ON	ON				
with ball	2			ON	OFF	ON				
(coin)	3			off	off	on				
	4			on	on	off				
	6			off	on	off				
	8			on	off	off				
	10			off	off	off				